
# Premier Heavy Duty 12" Wood Paper Trimmer - W12

Parts List






#### W12 PARTS LIST


#### W15 PARTS LIST

	Part Number	Description	Qy.	1	Part Number	Description	Qt.		Part Number	Description	Coy.		Part Number	Dos
1	M-O017909	LEFT REAR FOOT	1	12	M-0017642	LATCH SPACER	1	1	M-O017909	LEFT REAR FOOT	1	12	M-0017642	LATCH SPACE
2	M-S004018	#10 X 2 1/4 LOROOT FLHD	4	13	W-0017651	SMALL SAFETY LATCH	1	2	M-S004018	#10 X 2 1/4 LOROOT FLHD	4	13	W-0017651	SMALL SAFET
3	M-S004078	#8 X 7/8 PH PAN HD LR	5	14	M-S001148	10-32 X 7/8 PHL. P/HB/O	1	3	M-S004078	#8 X 7/8 PH PAN HD LR	5	14	M-S001148	10-32 X 7/8 PH
4	M-O017951	RIGHT REAR FOOT	1	15	W-O175012	12" CURVED BLADE	1	4	M-O017951	RIGHT REAR FOOT	1	15	W-0017735	15° CURVED B
5	M-S007010	10-32 ACORN NUT	1	16	M-S004063	#8 X 5/8 LR, W/#6 PH, F.H.	3	5	M-S007010	10-32 ACORN NUT	1	16	M-S004063	#8 X 5/8 LR. W
6	M-S61000058	10-32 HEX NUT	1	17	W-0017949	FINGERGUARD	1	6	M-S61000058	10-32 HEX NUT	1	17	W-0017950	FINGERGUAR
7	M-S001149	10-32 X 1.13 P/PH B/O	1	18	W-0010512	12" STRAIGHT BLADE	1	7	M-S001149	10-32 X 1.13 P/PH B/O	1	18	W-0010615	15" STRAIGHT
8	M-O017911	HANDLE CAP	1	19	M-0017906	RIGHT FOOT	1	8	M-O017911	HANDLE CAP	1	19	M-0017906	RIGHT FOOT
9	M-S001020	10-32 X 1/2 PHIL UC FH	3	20	M-S030010	T BUMPER (FOOT)	4	9	M-S001020	10-32 X 1/2 PHIL UC FH	4	20	M-S030010	T BUMPER (FO
10	M-S007033	HEX ACORN NUT, 10-32	1	21	M-C017905	LEFT FOOT	1	10	M-S007033	HEX ACORN NUT, 10-32	1	21	M-0017905	LEFT FOOT
11	M-S043012	7/8 HANDLE GRIP BLACK	1	22	M-S004016	#10 X 1 1/2 LOROOT FLHD	2	11	M-S043012	7/8 HANDLE GRIP BLACK	1	22	M-S004016	10 X 1 1/2 LOR



	Part Number	Description	Qty.	11	Part Number	Description	Qu		Part Number	Description			Part Number	Description	Qty.
1	M-C017946	W18 & 24 LIREAR FOOT	1	16	M-S007033	HEX ACORN NUT, 10-32	1	1	M-O017946	W18 & 24 L/REAR FOOT	1	16	M-S007033	HEX ACORN NUT, 10-32	1
2	W-F017920	W18 & 24 BEARING COVER	1	17	M-S043016	1" HAND GRIP, MAROON	1	2	W-F017920	W18 & 24 BEARING COVER	1	17	M-S043016	1" HAND GRIP, MAROON	1
3	M-S001169	#8 X 1/2 PH. PH. "B" ZING	4	18	M-O017642	LATCH SPACER	1	3	M-S001169	#8 X 1/2 PH. PH. "B" ZINC	4	18	M-0017642	LATCH SPACER	1
4	M-C017919	W18 & 24 R/REAR FOOT	1	19	W-0017652	LARGE SAFETY LATCH	1	4	M-O017919	W18 & 24 R/REAR FOOT	1	19	W-0017652	LARGE SAFETY LATCH	1
5	M-S004078	#8 X 7/8 LO ROOT PHIL	2	20	W-0017518	18" CURVED BLADE	1	5	M-S004078	#8 X 7/8 LO ROOT PHIL	2	20	W-0017524	24" CURVED BLADE	1
6	M-S007026	1/2-13 HEX LOCK NUT	1	21	M-S001149	10-32 X 1.13 P/PH B/O	1	6	M-S007026	1/2-13 HEX LOCK NUT	1	21	M-S001149	10-32 X 1.13 P/PH B/O	1
7	W-O001757	TORQUE WASHER	1	22	W-0017947	W18 FINGER GUARD	1	7	W-0001757	TORQUE WASHER	1	22	W-0017948	W24 FINGER GUARD	1
8	M-S031053	LG. TRIMMER SPRING	1	23	W-0010518	18" STRAIGHT BLADE	1	8	M-S031053	LG. TRIMMER SPRING	1	23	W-0010524	24" STRAIGHT BLADE	1
8	M-0017927	W18 & 24 HELICAL WEAR PAD	1	24	M-O017908	W18 & 24 R/FRONT FOOT	1	9	M-O017927	W18 & 24 HELICAL WEAR PAD	1	24	M-O017908	W18 & 24 R/FRONT FOOT	1
10	W-A017926	W18 BLADE/HANDLE ASSY	1	25	M-S030010	T BUMPER (FOOT)	4	10	W-A017929	W24 BLADE/HANDLE ASSY	1	25	M-S030010	T BUMPER (FOOT)	4
11	M-S002024	1/4-20X2 CUP PNT. SET SCREW	1	26	M-S004039	#10 X 1.5 PHL. P/H SCREW	4	11	M-S002024	1/4-20X2 CUP PNT. SET SCREW	1	26	M-S004039	#10 X 1.5 PHL. P/H SCREW	4
12	M-S004063	#8 X 5/8 W/#6 PHL. F/H SCREW	4	27	M-O017907	W18 & 24 L/FRONT FOOT	1	12	M-S004063	#8 X 5/8 W/#6 PHL. F/H SCREW	5	27	M-O017907	W18 & 24 LIFRONT FOOT	1
13	M-0017918	W18 & 24 HANDLE CAP	1	28	M-S004050	#10 X 2 PH. RD LO-ROOT	4	13	M-0017918	W18 & 24 HANDLE CAP	1	28	M-S004050	#10 X 2 PH. RD LO-ROOT	4
14	M-S007017	1/4-20 HEX NUT FULL	1	29	M-S004017	#10 X 1.25 PHL. F/H SCREW	1	14	M-S007017	1/4-20 HEX NUT FULL	1	29	M-S004017	#10 X 1.25 PHL. F/H SCREW	1
15	M-S001020	10-32 X 1/2 PHIL UC FH	6					15	M-S001020	10-32 X 1/2 PHIL UC FH	8				

# Premier® Heavy-Duty Paper Trimmers



# **Key Features and Benefits**

- Heavy-duty 3/4" thick wood base
- Fully-hardened self-sharpening steel blades cut up to 20 sheets
- Accurately cuts paper, matte board, cardboard, film, tissue, and textiles
- Permanent 1/2" grid and dual rulers for proper paper alignment
- Patented automatic blade latch locks with every cutting motion
- Finger guard helps protect the entire blade length
- Torsion spring counterbalances blade arm
- Non-skid feet

### Model Numbers


W12 – 12" cutting length

W15 - 15" cutting length

W18 – 18" cutting length W24 – 24" cutting length

Literature Part No. M-S027086 Rev. 8 11/12/14

MADE IN USA



# **Key Components**

- A Hand Grip/Blade Arm/Blade Latch Assembly
- B Wood Base with Molded End Caps
- C Alianment Ruler
- D Finger Guard
- E Paper Guide Ruler

## Assembly Instructions

Place the non-skid rubber feet into position on the bottom of the trimmer.

SAFETY LATCH

#### **Automatic Safety Latch**

The patented automatic blade latch is a key safety feature of this trimmer. It will lock with every complete cutting stroke, helping to eliminate forgetfulness. Remember to always push the blade arm down completely when you are finished cutting, to ensure that the latch activates. Never remove the latch for any reason.

AUTOMATIC BLADE

#### **Operating Instructions**

- 1. Place the trimmer on a flat, stable surface
- 2. Release the blade latch, which is located on the hand grip (A)
- 3. Lift the blade arm (A) up into cutting position
- 4. Using the rulers or the 1/2" grid, align the paper to the proper position, pushing it up against the paper guide ruler (E). It is recommended to use the guide ruler (E) as a point of reference only, paper should not be lined with this ruler. For a more accurate measurement, use the grid and alignment ruler (C).


#### **CAUTION:**

Keep hands and fingers behind the finger guard (D) at all times, away from the cutting blades

- 5. While holding the paper down with your left hand (to make sure it stays in place), pull down the blade arm (A) to cut.
- 6. Always make sure that the blade arm is completely down and locked when not in use.

# **ATTENTION:**

Do not force the blade arm upward beyond the natural stop position.



# Safety Information

- · Always ensure that the blade arm is fully pushed down, and that the blade latch is engaged, when not in use
- · Never operate the trimmer without the finger quard in place
- · Always keep clothing, jewelry, watches, and hair away from the cutting blade
- · Keep out of the reach of children
- Do not carry the trimmer by the hand grip or the blade arm

# For Best Cutting Performance

Use Trim-Ease Blade Lubricant for a smoother cut and to help preserve the life of the cutting blade. To order, please contact customer service at the number below and ask for Trim-Ease Blade Lubricant, part number MRS037046.

# <u>Customer Service</u>

Telephone: (260) 563-0641

Fax: (260) 563-4575

Email: info@martinyale.com

Internet: www.martinyale.com

Address: Martin Yale Industries, Inc. 251 Wedcor Avenue

Wabash, IN 46992

Visit www.martinyale.com for information on office products, including paper folding machines, punches, letter openers, catalog racks, and computer keyboard drawers.